


Note: Mounting brackets for securing legs to side panels and top are typical plumbers 3/8" threaded rod brackets. In the Lost Art Press blog Chris uses 14 brackets from McMaster-Carr (item # 11445T1) and one T-nut from McMaster-Carr (item #94122A200 or the 6 prong version 90975A163). In the drawing above I have used a recessed 11445T1 bracket to aide in securing the cleat to the bench instead of a T-nut.



Icale: Orthogonal Ireus 1:12 Gleat Ireus 1:8 Nôte: (Wboards 1 1/2"

Top & Leg Details

Nicholson Knockdown Work Bench

Original Drawing 6. Schwarz, Lost. Irt Bres Detail Brawing D RAM The Verona Compani.

TVC

